



Please Note:

This product is manufactured with tempered glass and could shatter if knocked or bumped.

COMPONENTS:

- 1 x glass panel with wall profile (a)
- 1 x wall fixation channel (b)
- 3 x plated caps and rings
- 3 x 4.2 * 9.5 stainless steel screws to lock panel in position to wall profile
- 3 x 4.2 * 38 stainless steel screws to fit wall profile to wall
- 1 x wall fitting: lug and cover (c)
- 1 x glass fitting (d)
- 1 x 1m stabilising bar (e)
- 1 x floor block (f)

INSTRUCTIONS:

1. Mark the allocated position for the glass panel on the wall.
2. Fit the wall fixation channel level and square to the floor and the wall.
3. Fit the glass panel in the wall fixation channel.
4. Mark the position of the floor block.
Remove the glass to drill for the floor block.
5. Install the wall fittings for the stabilising bar.
6. Line up the glass fitting for the stabilising bar at 90 degrees to the glass.
7. Lock the glass into position with the screws provided and fasten the floor block.
8. Seal the bottom of the shower screen with silicone and leave for 24 hours to properly cure.

Special Note to Installer & End-User:

This product is made from the highest quality components and glass. The glass used is toughened safety glass according to SABS standards and complies with National Safety Standards and building regulations.



WARNING

Toughened safety glass is designed to break safely in instances of accidental damaged. However, toughened safety glass remains a glass product, which, when shattered, can result in injury. Both Lecico and the manufacturer cannot accept any liability for accidental breakage – at any point in time – by any cause whatsoever.

